



# MagCARD Program

Zon Jr. XL, XL-300

## Sale (swiped)

Action	Terminal Display
1. Swipe card through reader or see "Manual Entry"	Enter Last 4 Number
2. Key the last 4 digits of card number; Press ENTER	Amount of Sale
3. Key amount of sale; press ENTER	"Transmitting"

## Refund (swiped)

Action	Terminal Display
1. Press [2] for CREDIT	Enter Account #
2. Swipe card through reader or see "Manual Entry"	Amount of CREDIT
3. Key in amount of credit; press ENTER	"Processing"

## Force (swiped)

Action	Terminal Display
1. Press [3] for FORCE	Enter Account #
2. Swipe card through reader or see "Manual Entry"	Amount of FORCE
3. Key amount of force, press ENTER	Enter Auth Code
4. Key approval code; press ENTER	"Processing"

## Void

Action	Terminal Display
1. Press [5] for VOID	Tran # to VOID
2. Key transaction number to void; Press ENTER	Account # follows 12345*****
3. Verify card number and press ENTER	\$**.** SALE
4. Verify amount and transaction type and press ENTER	VOID this tran?
5. Press ENTER to void; if incorrect, press CLEAR to about transaction	Tran ## Voided



# MagCARD Program

Zon Jr. XL, XL-300

## Manual Entry

Action	Terminal Display
1. Press desired key: 1 for PURCHASE 2 for CREDIT 3 for FORCE 4 for AUTH	Enter Account #
2. Key card number; Press ENTER	Expir Date MM/YY
3. Key expiration date (MMYY); Press ENTER	Amount of _____
4. Key amount of transaction; press ENTER	"Transmitting"

## Batch Summary Report

Action	Terminal Display
1. Press ENTER, [6]	Print Batch Rpt?
2. Press ENTER	"Printing"

## Batch Detail Review

Action	Terminal Display
1. Press ENTER, [9]	Enter 1 = Total 2 = Detail
2. Press [1] for Batch Totals; press ENTER	Set ** = \$***.**
3. Press ENTER to scroll through each transaction	

## Batch Settlement

Action	Terminal Display
1. Press [6]	Enter Password
2. Enter password (166831); press ENTER	"Transmitting"